



Steel Tray Wheelbarrow

Assembly Manual




Estimated Assembly
Time: 20 Minutes

WHEELBARROW ASSEMBLY

TOOLS REQUIRED


- 14mm Extended socket
- 14mm Spanner
- Sticky Tape

PARTS INCLUDED



M8 BOLTS


S1 = 20mm **S3** = 65mm
S2 = 45mm **S4** = 100mm



Note: When assembling bolts the correct order is to:

1. Place bolt through material
2. Put the flat washer on the bolt
3. Place the spring washer on top of the flat washer
4. Finally place the nut over both the flat washer and Spring washer

WHEELBARROW ASSEMBLY



Step 1.

Place S4 bolts in the slots at the shallow end of the tub.



Step 2.

Place S5 bolts in the slots at the deep end of the tub.



Step 3.

Place Support Mat (3) over the tub, place it in the same direction as shown in the image above.



Step 4.

Once the mat is in position, place the support struts (4) on the bolts as shown above.

WHEELBARROW ASSEMBLY



Step 5.

Place Support Mat (3) on tub with the flat side away from the tub as shown.



Step 6.

Place the handles (6) on the bolts.

Note: There are indents on one side of the handles; have these indents touching the support struts.



Step 7.

Place stand (6) in place.



Step 8.

Secure the bolt with washer, spring washer and the nut.

8



WHEELBARROW ASSEMBLY



Step 9.

Place S1 bolts through the front slots.



Step 10.

Place front support arms (8) through S1 bolts as well.

Step 11.

Secure the bolt with washer, spring washer and the nut.



Step 12.

Attach support arms to the handles using S3 bolts.

Step 13.

Secure the bolt with washer, spring washer and the nut.

Note: Bolts must be inserted upwards to ensure the bolt is the correct way up.

WHEELBARROW ASSEMBLY



Step 14.

Attach nose guard (9) to handles using S2 bolts.

Step 15.

Place flat and spring washers and lock with nut.

WHEELBARROW ASSEMBLY



Step 16.

Place shaft (11) through the wheel (10).



Step 17.

Slide the wheel supports (12) on both sides of the shaft.



Step 18.

Place wheel assembly on top of the handles (5) and secure with S3 bolts.



Step 19.

Secure the bolt with washer, spring washer and nut.

When tightening the wheel supports, align them evenly so the wheel is centered. Once the wheel is in place, all other bolts can be tightened.

Note: With the wheelbarrow in the upright position, all bolts should be facing downwards (or inwards in the case of the nose guard).